

Historic, archived document


Do not assume content reflects current
scientific knowledge, policies, or practices.

756.19
R 31
cop. 2

U. S. DEPT. OF AGRICULTURE
NATIONAL AGRICULTURAL LIBRARY

JUL 8 1966

CURRENT SERIAL RECORDS



STORAGE FLOOD ROUTING WITHOUT COEFFICIENTS

June 1966 ARS 41-122

Agricultural Research Service

UNITED STATES DEPARTMENT OF AGRICULTURE

CONTENTS

	Page
Introduction.....	3
Formulation	3
Solution Formulation.....	6
Solution Program.....	7
Examples	7
Consistency of the Storage Flood Routing Method.....	14
Conclusions.....	16
Literature Cited.....	20
Symbols Used in the Program.....	20
Appendix 1	23
Main Line Program	23
Read and Table Look-up Subroutines	25
Solve Subroutine.....	26
Appendix 2	27
Program Input Format	27
Program Output Format	27
Loading Sequence.....	27

Trade names and company names are used in this publication solely to provide specific information. Mention of a trade name does not imply any endorsement of preferential treatment of the product listed by the U.S. Department of Agriculture.

STORAGE FLOOD ROUTING WITHOUT COEFFICIENTS

D. L. Brakensiek¹

INTRODUCTION

Flood routing methods that are based on the conservation of mass (continuity) and a single-valued relationship between depth of flow and flow rate are usually termed "storage flood routing" methods. This type of formulation is discussed more rigorously under the theory of kinematic waves. A fundamental reference to this theory is made by Lighthill and Whitham (7).²² Henderson (4) considered the kinematic treatment of flood waves in prismatic channels. More recently, Henderson and Wooding (5) applied the kinematic wave theory to the overland flow problem.

Many hydrologists using storage flood routing utilize coefficients, such as X and K of the Muskingum method (2) or C of the convex method.³ This report presents a numerical method for storage flood routing without coefficients. A number of flow problems are solved with a computer program. Some limitations of the kinematic formulation are illustrated by example.

FORMULATION

The formulation of storage of kinematic flood routing is composed of the continuity equation

$$\frac{\partial Q}{\partial x} + \frac{\partial A}{\partial t} = q \quad (1)$$

and a rating function

$$Q = Q(A) \quad (2)$$

where

Q = flow rate, c.f.s.,

A = flow area, ft.²,

q = lateral inflow (+) or lateral outflow (-), c.f.s./ft., and

x, t = distance (feet) and time (seconds) coordinates.

¹Research hydraulic engineer, Soil and Water Conservation Research Division, Agricultural Research Service, U.S. Department of Agriculture.

²Underscored numbers in parentheses refer to Literature Cited, page 20.

³Mockus, Victor, Chapter II, Computer program for project formulation hydrology. Prepared for Soil Conservation Service, U.S. Department of Agriculture, by C-E-I-R, Inc. January 1964.

The salient features of the continuity equations are obtained by substituting $Q = AV$ into equation 1, differentiating the product, and multiplying both sides by $\Delta t \Delta x$, to obtain volumes,

$$\Delta x \Delta t \left(\overset{(a)}{\frac{A \partial V}{\partial x}} + \overset{(b)}{\frac{V \partial A}{\partial x}} + \overset{(c)}{\frac{\partial A}{\partial t}} \right) = q(\Delta x \Delta t).$$

where

V = velocity, ft./sec.
 Δt = time increment, sec.
 Δx = length increments, ft.

The terms on the left-hand side are usually referred to as follows:

- (a) - prism storage,
- (b) - wedge storage, and
- (c) - time rate of change of storage.

The usual treatment of equations 1 and 2 is to recast them as follows:

Using the grid pattern in figure 1, equation 1 can be written (with $q = 0$),




Figure 1.--Grid for finite difference approximations.

$$\frac{\partial Q}{\partial x} = \frac{Q_4 - Q_2}{\Delta x}$$

$$\frac{\partial A}{\partial t} = \frac{A_4 - A_3 + A_2 - A_1}{2 \Delta t}$$

$$\bar{q} = \frac{q_4 + q_2}{2}$$

$$\frac{Q_4 - Q_2}{\Delta x} + \frac{(A_4 + A_2) - (A_3 + A_1)}{2\Delta t} = 0$$

or

$$Q_4 - Q_2 + \left(\frac{(A_4 + A_2)}{2} \Delta x - \frac{(A_3 + A_1)}{2} \Delta x \right) \frac{1}{\Delta t} = 0. \quad (3a)$$

Now if we define

$$S_2 = \left(\frac{(A_4 + A_2)}{2} \right) \Delta x = \text{storage at } t = t + \Delta t,$$

$$S_1 = \frac{(A_3 + A_1)}{2} \Delta x = \text{storage at } t = t,$$

$$Q_4 = O = \text{outflow, and}$$

$$Q_2 = I = \text{inflow,}$$

The equation 3a can be written

$$I - O = \frac{S_2 - S_1}{\Delta t}$$

or

$$(I - O) \Delta t = \Delta S. \quad (3b)$$

Equation 3b is similar to the usual continuity expression (inflow - outflow = change of storage). Storage is evaluated as

$$S = S(O) \quad (4)$$

or

$$S = S(O, I) \quad (5)$$

where

$$S = \text{storage, c.f.s.-hrs.,}$$

$$O = \text{outflow, c.f.s., and}$$

$$I = \text{inflow, c.f.s.}$$

Equation 4 is used by methods that neglect wedge storage, such as the storage-indication method. Equation 5 is used by the Muskingum method where two coefficients X and K are introduced to account for both prism and wedge storage. The development in this report is based on only equations 1 and 2, i.e., no functional form is assumed for relating reach storage to inflow and outflow. The assumption inherent in kinematic wave theory is not altered; i.e., the equation of motion can be approximated by a single-valued function, equation 2.

SOLUTION FORMULATION

A simultaneous solution of equations 1 and 2 is accomplished by obtaining a numerical solution on a small computer (IBM 1620, 40 K memory and indirect addressing). Equation 1 is approximated by the finite difference quotients shown in figure 1. Substituting these quotients into equation 1, one obtains:

$$\frac{Q_4 - Q_2}{\Delta x} + \frac{A_4 - A_3 + A_2 - A_1}{2\Delta t} = \bar{q}$$

or

$$\frac{\Delta t}{\Delta x} Q_4 + \frac{A_4}{2} = \left(\frac{A_1 + A_3}{2} \right) + \frac{\Delta t}{\Delta x} Q_2 + \left(\frac{-A_2}{2} + \Delta t \bar{q} \right)$$

or

$$\lambda Q_4 + \frac{A_4}{2} = \alpha + \beta \tag{6}$$

where

$$\lambda = \Delta t / \Delta x,$$

$$\alpha = (A_1 + A_3) / 2, \text{ and}$$

$$\beta = \lambda Q_2 + \left(\frac{-A_2}{2} + \Delta t \bar{q} \right).$$

The subscripts in these equations are defined as follows:

A_1 = flow area at location x and time t ,

A_3 = flow area at location $x + \Delta x$ and time t ,

A_2, Q_2 = flow area or rate at location x and time $t + \Delta t$, and

A_4, Q_4 = flow area or rate at location $x + \Delta x$ and time $t + \Delta t$.

Equation 2 is retained in the computer memory as an array of numerical values, i.e., paired Q and A values.

The rating functions are determined by one of several procedures. If normal flow (turbulent flow) is assumed, the Manning or Chezy equation can be applied at each channel section. An alternative for natural channels is to calculate a series of water surface profiles; e.g., using U.S. Department of Agriculture Hydrograph Laboratory Computer Program No. 2 (8). The computed values for rates of flow and depths of flow at each section along the channel system define a section rating function.

Since the rating function is not an explicit function but a set of numerical values, a simultaneous solution of equations 6 and 2 requires an iteration procedure. In this study, the procedure used is known as the method of false position 6. A special constraint is required to account for incipient flow at downstream sections during rising stages and for cessation of flow at upstream sections during falling stages, i.e., for value of $(\alpha + \beta) \leq 0$, Q_4 and A_4 are set equal to base flow.

SOLUTION PROGRAM

Presented in appendix 1 are the source programs for the main line and three subroutines. These programs are written in Fortran II.

Program input and output formats are presented in appendix 2. Arrays of data are read in by way of the "Read" subroutine. Flow area values are calculated for flow rate values by an interpolation function. Arguments are obtained from the "Table Look-up" subroutine. One limitation on inflow input is that the final rate of inflow must equal the initial value (return to a dry channel or to the initial base flow). Note that lateral flow hydrographs must have the same number of entries as the inflow hydrograph. Dummy zeros can be entered.

In storage flood routing methods, calculations proceed, as usual, in a downstream direction. An inflow hydrograph is given at the upstream section as a boundary condition. For overland flow applications, this is the "null" hydrograph. The initial conditions are known rates of flow and flow areas. These can be zero if a dry channel is assumed. If base flow is assumed, flow area should be calculated from the section rating functions. Lateral flow (q) can be put in as a plus quantity for local inflows or as a minus quantity for transmission losses. Inflow from a tributary can be treated as lateral flow introduced over a short channel length.

Initially the program section, "Routing During Inflow," determines the time of incipient flow at the next downstream section; thereafter, inflow is routed by application of the "Solve" subroutine. This subroutine performs the iteration solution of equation 6 with discharge values calculated from the rating function table. Iteration cycling is terminated by a tolerance (TOLR) level.

After the last value of inflow has been routed, computations are transferred to the main line program section "Routing After Inflow" section of the program. Routing computations continue until downstream outflow decreases to a value within 0.1 of the initial value; the last outflow entry is then set equal to the initial inflow value. All input data arrays are filled out to correspond in length to the outflow arrays. During solution punch out, outflow section data are interchanged with inflow section data so as to become inflow data for the next routing reach. After data arrays are read in for the next outflow section, computations proceed for the next routing reach. Problem solution is complete after the last section data have been read in and a Reader "no feed" signal occurs on the IBM 1620 console.

EXAMPLES

Example 1 is an inflow hydrograph introduced on a constant base flow of 150 c.f.s. Manning's equation was utilized for the rating function of a theoretical rectangular channel 30 feet wide, with a bed slope of 0.001 and an n -value of 0.03. Since this was a prismatic channel, the rating functions are the same at all sections of the channel. The time scale increment (Δt) was 3,600 seconds, and the distance scale increment (Δx) was 7,200 feet. Table 1 presents program input and table 2 presents the program output. Figure 2 is a succession of routed hydrographs. Figure 3 is a typical storage outflow function generated by the routing method. The storage values were calculated by the average end-area method. The storage loop indicates the importance of wedge storage. If the wedge storage term in the continuity equation were neglected, the relationship would be a single-valued curve.

For example 2, an inflow hydrograph was introduced on an initially dry channel with a constant (in time and space) lateral outflow (q) of 0.05 c.f.s./ft. The same channel geometry was used as in example 1, and Manning's equation was used to calculate the rating functions. The program input is presented in table 3. A succession of routed hydrographs is presented in figure 4. The rather uniform decline in the hydrograph results from the constant transmission loss.

Figure 5 presents two additional surface flow problems. Presented in figure 5 at top, is a set of hydrographs resulting from a constant inflow of 150 c.f.s. This problem would be typical of the border of furrow irrigation problem. Also, releases from a detention reservoir might lead to a similar problem. In this example, transmission losses were set to zero. The program input for this example is given in table 4. Figure 5, at bottom, illustrates the overland flow

Table 1.--Input for example 1


[illegible]

Figure 2.--Succession of routed hydrographs.

Table 2.--Output for example 1

IN SECTION NO = 1

IN AREA	IN DISCH
62.915	150.000
118.357	400.000
162.843	650.000
231.783	1088.000
328.012	1775.000
456.162	2775.000
576.877	3775.000
635.632	4275.000
650.242	4400.000
635.632	4275.000
584.340	3838.000
524.637	3338.000
456.162	2775.000
401.534	2338.000
353.016	1963.000
311.326	1650.000
268.029	1338.000
231.783	1088.000
203.688	900.000
173.232	713.000
141.375	525.000
118.357	400.000
92.637	275.000
62.915	150.000
62.915	150.000
62.915	150.000
62.915	150.000
62.915	150.000

OUT SECTION NO = 2

OUT AREA	OUT DISCH
62.915	150.000
99.849	307.579
147.341	557.596
211.841	954.559
302.998	1587.613
424.965	2524.881
547.966	3531.256
620.306	4143.905
645.582	4360.114
638.202	4296.988
595.476	3932.010
538.697	3454.469
472.599	2909.573
415.538	2449.689
365.748	2061.307
322.645	1734.789
280.105	1423.800
242.763	1161.472
212.420	958.435
183.072	772.670
152.521	587.407
127.306	448.132
103.261	324.558
76.982	205.916
65.720	161.147
63.475	152.223
63.027	150.443
62.915	150.000

IN SECTION NO = 2

IN AREA	IN DISCH
62.915	150.000
99.849	307.579
147.341	557.596
211.841	954.559
302.998	1587.613
424.965	2524.881
547.966	3531.256
620.306	4143.905
645.582	4360.114
638.202	4296.988
595.476	3932.010
538.697	3454.469
472.599	2909.573
415.538	2449.689
365.748	2061.307
322.645	1734.789

OUT SECTION NO = 3

OUT AREA	OUT DISCH
62.915	150.000
86.461	247.099
130.575	465.990
192.227	828.188
278.227	1410.453
394.877	2286.205
518.228	3284.904
602.050	3987.742
638.380	4298.508
638.993	4303.754
604.556	4009.174
551.875	3563.929
488.422	3039.118
430.014	2565.149
378.825	2162.272
334.335	1822.364

Table 2.--Output for example 1--Continued

280.105	1423.800	292.033	1508.545
242.763	1161.472	253.818	1237.030
212.420	958.435	221.745	1020.835
183.072	772.670	192.665	830.846
152.521	587.407	162.528	648.094
127.306	448.132	136.630	499.075
103.261	324.558	112.799	372.226
76.982	205.916	88.473	256.190
65.720	161.147	72.484	188.034
63.475	152.223	65.718	161.139
63.027	150.443	63.653	152.931
62.915	150.000	63.085	150.673
62.915	150.000	62.949	150.134
62.915	150.000	62.915	150.000

IN SECTION NO = 3

IN AREA	IN DISCH
62.915	150.000
86.461	247.099
130.575	465.990
192.227	828.188
278.227	1410.453
394.877	2286.205
518.228	3284.904
602.050	3987.742
638.380	4298.508
638.993	4303.754
604.556	4009.174
551.875	3563.929
488.422	3039.118
430.014	2565.149
378.825	2162.272
334.335	1822.364
292.033	1508.545
253.818	1237.030
221.745	1020.835
192.665	830.846
162.528	648.094
136.630	499.075
112.799	372.226
88.473	256.190
72.484	188.034
65.718	161.139
63.653	152.931
63.085	150.673
62.949	150.134
62.915	150.000
62.915	150.000

OUT SECTION NO = 4

OUT AREA	OUT DISCH
62.915	150.000
77.694	208.744
115.222	384.332
172.598	709.159
254.583	1242.469
365.414	2058.725
488.359	3038.602
581.156	3811.123
628.588	4214.746
637.840	4293.889
611.644	4069.808
563.784	3664.470
503.495	3162.859
444.704	2682.313
392.244	2265.878
346.389	1912.664
303.778	1593.458
264.697	1314.324
231.493	1086.063
202.093	889.326
172.390	707.893
146.123	550.939
122.143	419.922
98.883	303.215
80.855	221.774
70.075	178.460
65.344	159.655
63.648	152.914
63.116	150.796
62.962	150.185
62.915	150.000




Figure 3.--Reach storage-outflow relationship.




Figure 4.--Succession of routed hydrographs with a constant transmission loss.

Table 3.--Input for example 2

3600	3600	50	50	1	27	35												001
0		1		2		4		7		11		16		23		30	1 1 00	
40		50		60		80		100		120		150		200		250	2 1 00	
300		350		400		450		500		550		600		650		700	3 1 00	
800		900		1000		1100		1200		1300		1400		1500			4 100	
0	.1633		.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092		1 1 11	
72.3008	103.49		138.41		217.91		308.26		408.21		572.12		875.32		1209.9		2 1 11	
1565.15	1939.71		2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0		3 1 11	
5709.5	6601		7503		8408		9326		10245		11177		12103				4 1 11	
0	250		650		1188		1775		2775		3775		4275		4400		1 1 22	
4275	3838		3338		2775		2338		1963		1650		1338		1088		2 1 22	
900	713		525		400		27		0		0		0		0		3 1 22	
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
0	1		2		4		7		11		16		23		30	1 1 00		
40	50		60		80		100		120		150		200		250	2 1 00		
300	350		400		450		500		550		600		650		700	3 1 00		
800	900		1000		1100		1200		1300		1400		1500			4 100		
0	.1633		.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092		1 1 11	
72.3008	103.49		138.41		217.91		308.26		408.21		572.12		875.32		1209.9		2 1 11	
1565.15	1939.71		2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0		3 1 11	
5709.5	6601		7503		8408		9326		10245		11177		12103				4 1 11	
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
-.05	-.05		-.05		-.05		-.05		-.05		-.05		-.05		-.05			
7200	0																002	

Table 4.--Input for example shown in figure 5, at top

3600	3600	50	50	1	27	35												001
0		1		2		4		7		11		16		23		30	1 1 00	
40		50		60		80		100		120		150		200		250	2 1 00	
300		350		400		450		500		550		600		650		700	3 1 00	
800		900		1000		1100		1200		1300		1400		1500			4 100	
0	.1633		.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092		1 1 11	
72.3008	103.49		138.41		217.91		308.26		408.21		572.12		875.32		1209.9		2 1 11	
1565.15	1939.71		2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0		3 1 11	
5709.5	6601		7503		8408		9326		10245		11177		12103				4 1 11	
0	150		150		150		150		150		150		150		150			
150	150		150		150		150		150		150		150		150			
150	150		150		150		150		150		150		150		150			
0	0		0		0		0		0		0		0		0		1 1 22	
0	0		0		0		0		0		0		0		0		2 1 22	
0	0		0		0		0		0		0		0		0		3 1 22	
0	1		2		4		7		11		16		23		30	1 1 00		
40	50		60		80		100		120		150		200		250	2 1 00		
300	350		400		450		500		550		600		650		700	3 1 00		
800	900		1000		1100		1200		1300		1400		1500			4 100		
0	.1633		.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092		1 1 11	
72.3008	103.49		138.41		217.91		308.26		408.21		572.12		875.32		1209.9		2 1 11	
1565.15	1939.71		2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0		3 1 11	
5709.5	6601		7503		8408		9326		10245		11177		12103				4 1 11	
0	0		0		0		0		0		0		0		0		1 1 22	
0	0		0		0		0		0		0		0		0		2 1 22	
0	0		0		0		0		0		0		0		0		3 1 22	
7200	0																	002





Figure 5. --Top, Succession of hydrographs with a constant inflow at top section;
Bottom, Succession of overland flow hydrographs.

problem. Inflow is a uniform and constant lateral rate of 0.005 c.f.s./ft. The rate could be assumed to be falling over a watershed and could be varied so as to evaluate the influence of temporal and spatial variations of rainfall. Program input is presented in table 5.

Table 5.--Input for example shown in figure 5, at bottom

3600	3600	50	50	1	27	35													001
0			1		2		4		7		11		16		23		30	1	1 00
40		50			60		80		100		120		150		200		250	2	1 00
300		350			400		450		500		550		600		650		700	3	1 00
800		900			1000		1100		1200		1300		1400		1500			4	100
0		.1633			.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092	1	1 11
72.3008		103.49			138.41		217.91		308.26		408.21		572.12		875.32		1209.9	2	1 11
1565.15		1939.71			2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0	3	1 11
5709.5		6601			7503		8408		9326		10245		11177		12103			4	1 11
0		0			0		0		0		0		0		0		0	1	1 22
0		0			0		0		0		0		0		0		0	2	1 22
0		0			0		0		0		0		0		0		0	3	1 22
.005		.005			.005		.005		.005		.005		.005		.005		.005		
.005		.005			.005		.005		.005		.005		.005		.005		.005		
.005		.005			.005		.005		.005		.005		.005		.005		.005		
0		1			2		4		7		11		16		23		30	1	1 00
40		50			60		80		100		120		150		200		250	2	1 00
300		350			400		450		500		550		600		650		700	3	1 00
800		900			1000		1100		1200		1300		1400		1500			4	100
0		.1633			.5179		1.6369		4.1364		8.7595		16.2298		29.4354		45.4092	1	1 11
72.3008		103.49			138.41		217.91		308.26		408.21		572.12		875.32		1209.9	2	1 11
1565.15		1939.71			2325.76		2724.55		3133.9		3548.1		3970.2		4397.9		4831.0	3	1 11
5709.5		6601			7503		8408		9326		10245		11177		12103			4	1 11
.005		.005			.005		.005		.005		.005		.005		.005		.005		
.005		.005			.005		.005		.005		.005		.005		.005		.005		
.005		.005			.005		.005		.005		.005		.005		.005		.005		
7200		0																	002

CONSISTENCY OF THE STORAGE FLOOD ROUTING METHOD

A vexing characteristic of storage flood routing methods is the dependence of calculated discharges on the selection of reach lengths (Δx) and time increments (Δt). An indication of this difficulty with respect to storage flood routing with coefficients Muskingum was discussed by Gilcrest 3, thus: "However, it has been found that actual flood hydrographs along several hundred miles of river can, through judicious selection of routing reaches and time interval used in routing, be duplicated quite accurately..."

Several numerical trials were made to evaluate the influence of Δx and Δt on the storage flood routing without coefficients method. Tables 6 and 7 represent the routing of the same inflow hydrograph used in example 1. Three reach lengths are combined with two time increments. The indication is that the effect of Δx over the range shown here for a constant Δt is small. However, an influence of Δt is clearly evident.

Table 8 presents a set of routings for a triangular-shaped hydrograph inflow into a prismatic channel. The conclusion is that the peak reduction is completely dependent on Δt .

This conclusion was first pointed out by Thomas (9). Especially evident from table 8 is a possible trend toward no crest reduction. This is in agreement with the work of Henderson (4) on kinematic waves. Thus, the method of storage flood routing is converging on the correct result. In view of the approach to a condition of no peak reduction as $\Delta t \rightarrow 0$, an effort is required to select Δt so as to approximate the true peak reduction condition. Presented in

Table 6.--Comparison of hydrographs for a time increment of 1 hour
with three reach lengths

Time (hours)	Hydrograph discharge		
	$\Delta x = 3,600$ feet	$\Delta x = 7,200$ feet	$\Delta x = 14,400$ feet
	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>
0	150	150	150
2	183	182	179
4	560	560	561
6	1,866	1,866	1,867
8	3,502	3,503	3,507
10	4,117	4,117	4,118
12	3,665	3,665	3,663
14	2,804	2,804	2,802
16	2,038	2,038	2,038
18	1,443	1,443	1,443
20	1,001	1,001	1,001
22	667	667	667
24	419	419	420
26	263	263	261
28	187	187	187
30	158	159	159
32	151	151	152
34	150	150	150
36	150	150	150

Table 7.--Comparison of hydrographs for a time increment of one-half hour
with three reach lengths

Time (hours)	Hydrograph discharge		
	$\Delta x = 3,600$ feet	$\Delta x = 7,200$ feet	$\Delta x = 14,400$ feet
	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>
0	150	150	150
2	158	157	150
4	443	445	452
6	1,768	1,769	1,771
8	3,622	3,623	3,628
10	4,262	4,262	4,260
12	3,708	3,767	3,765
14	2,816	2,816	2,814
16	2,023	2,024	2,024
18	1,435	1,435	1,435
20	994	994	995
22	662	662	662
24	410	411	412
26	243	243	241
28	169	169	171
30	150	152	153
32	150	150	150
34	150	150	150
36	150	150	150

Table 8.--Comparison of hydrographs for several time intervals with a constant reach length (prismatic channel)

Time (hours)	Inflow	Outflow 72,000 feet downstream for Δt of--			
		1/10 hour	1/4 hour	1/2 hour	1 hour
	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>
0	150	150	150	150	150
1/2	600	150	150	150	--
1	1,200	150	150	150	159
1 1/2	1,800	150	150	151	--
2	2,400	150	150	159	260
2 1/2	3,000	150	150	204	--
3	3,600	150	177	391	733
3 1/2	4,200	286	531	827	--
4	4,800	1,276	1,330	1,476	1,721
4 1/2	4,390	2,260	2,206	2,207	--
5	3,975	3,045	2,989	2,898	2,801
5 1/2	3,575	3,741	3,636	3,451	--
6	3,180	4,277	4,060	3,801	3,460
6 1/2	2,790	4,402	4,193	3,933	--
7	2,400	4,194	4,075	3,875	3,551

tables 9 and 10 are the comparisons of the selection of Δt in the storage flood routing procedure so as to correspond to the peak reduction found with a higher order routing method (1). A Δt in the range of one-fourth to one-half hour appears to give a satisfactory correspondence. Figures 6 and 7 show the tabular comparison between routed hydrographs for two different hydrograph shapes. In figure 7, the 1/4-hour hydrograph could not be shown since it fell too close to the hydrograph predicted by the higher order routing method.

CONCLUSIONS

Formulation of the unsteady, non-uniform open channel flow problem in pure kinematics leads to a simple problem for solution. The computer program listed here appears to be functioning quite well over a wide spectrum of problems.

An unavoidable feature of storage flood routing methods is still of concern; namely, the selection of the reach length (Δx) and time increment (Δt). Tentative results of the numerical testing in this report indicate that the only concern in selecting the reach length is to fit the physical dimension of the channel system. However, the time increment selection has major influence on the shape of the routed hydrograph. For two extreme inflow hydrograph shapes, several time increment comparisons were made with a higher order routing method, i.e., a more complete equation of motion was utilized. The best correspondence occurred when the time increment was $\Delta t = t_p/16$

where

t_p = time to peak of the inflow graph.

Future development for this routing method will require extensive testing with data from actual floodflow situations. It may happen that the strongly nonprismatic character of actual channels may reduce the influence of time increments.

Table 9.--Comparison of storage flood routing read in 1/2-hour time increment without coefficients with a higher order formulation

Time (hours)	Inflow	Outflow ¹	Outflow ²	
			$\Delta t = 1/4$ hour	$\Delta t = 1/2$ hour
	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>
0	150	150	150	150
1/2	600	150	150	150
1	1,200	150	150	150
1 1/2	1,800	150	150	151
2	2,400	150	150	159
2 1/2	3,000	150	150	204
3	3,600	159	177	391
3 1/2	4,200	390	531	827
4	4,800	1,380	1,330	1,476
4 1/2	4,390	2,455	2,206	2,207
5	3,980	3,126	2,989	2,898
5 1/2	3,580	3,703	3,636	3,451
6	3,180	4,002	4,060	3,801
6 1/2	2,790	4,062	4,193	3,933
7	2,400	3,923	4,075	3,875

¹ Calculated with the equation of motion, neglecting only the inertia forces.

² Calculated by storage flood routing without coefficients.

Table 10.--Comparison of storage flood routing read in hourly time increments without coefficients with a higher order formulation

Time (hours)	Inflow	Outflow ¹	Outflow ²		
			$\Delta t = 1/4$ hour	$\Delta t = 1/2$ hour	$\Delta t = 1$ hour
	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>	<u>C.f.s.</u>
0	150	150	150	150	150
1	400	154	150	150	150
2	650	157	150	157	182
3	1,075	182	150	213	288
4	1,775	349	380	445	559
5	2,775	921	910	949	1,082
6	3,775	1,810	1,730	1,769	1,866
7	4,275	2,837	2,790	2,767	2,753
8	4,400	3,737	3,700	3,623	3,503
9	4,275	4,176	4,190	4,119	3,970
10	3,875	4,274	4,320	4,262	4,117
11	3,375	4,101	4,150	4,119	3,988
12	2,775	3,742	3,800	3,767	3,665

¹ Calculated with the equation of motion, neglecting only the inertia forces.

² Calculated by storage flood routing without coefficients.




Figure 6.--Storage flood routing with different time increments compared with a higher-order formulation.




Figure 7.---Storage routing with different time increments compared with a higher-order formulation.

LITERATURE CITED

- (1) Brakensiek, D. L., Heath, A. L., and Comer, G. H.
1966. Numerical techniques for small watershed flood routing. U.S. Dept. Agr., Agr. Res. Serv. ARS 41-113, 40 pp.
- (2) Chow, Ven Te.
1959. Open channel hydraulics. 680 pp. McGraw-Hill Book Co., Inc., New York.
- (3) Gilcrest, B. R.
1950. Flood routing. In Rouse, Hunter, Engineering Hydraulics, pp. 635-710. John Wiley and Sons, Inc., New York.
- (4) Henderson, F. M.
1963. Flood waves in prismatic channels. Amer. Soc. Civil Engin. Proc., Hydraul. Div. Jour. 89(HY4): 39-67.
- (5) _____ and Wooding, R. A.
1964. Overland flow and groundwater from a steady rainfall of finite duration. Jour. Geophys. Res. 69(8): 1531-1540.
- (6) Kunz, K. S.
1957. Numerical analysis. 381 pp. McGraw-Hill Book, Co., Inc., New York.
- (7) Lighthill, M. J., and Whitham, G. B.
1955. Kinetic waves. I. Royal Soc. London, Proc., Ser. A., 229: 281-316.
- (8) Shanholtz, V. O., and Holtan, H. N.
1965. Computer program USHL No. 2: Water surface profiles from spatially varied flow in natural channels. U.S. Dept. Agr., Agr. Res. Serv. ARS 41-101, 38 pp.
- (9) Thomas, H. A.
1934. Hydraulics of flood movements in rivers. 70 pp. Carnegie Institute of Technology.

SYMBOLS USED IN THE PROGRAM

Symbol	Description
<u>Input:</u>	
DELT	Time increment used in routing computations (constant) in seconds
DELT1	Same as DELT, saved for initialization
DELA	Area increment in rating table (see Solve subroutine)
DELA1	Same as DELA, saved for initialization
TOLR	Tolerance (see Solve subroutine)
N1	Number of inflow hydrograph entries
N2	Number of tabulated rating function entries
AREA1(I) } DISCH1(I) } AREA2(I) } DISCH2(I) }	Entries in the upper and lower section rating function tables

Symbol	Description
(I = 1, N2)	
Q1(I)	Entries in the inflow hydrograph
QL1(I) } QL2(I) }	Entries in the upper and lower lateral inflow hydrographs
(I = 1, N1)	
Q2(I)	Initial flow rate at the lower section
(I = 1)	
DELX	Distance increment (can be changed for each reach)

Output:

LL1	Upper section number
LL2	Lower section number
A1(I) } Q1(I) }	Upper section flow area and flow rate
A2(I) } Q2(I) }	Lower section flow area and flow rate
(I = 1, M)	

Main Program:

READ	See Read subroutine
TBLLP	See Table Look-up subroutine
XINT	Function for interpolation
(C, D, E, F, G)	<u>Arithmetic statement arguments</u>
	C - Lower bound for wanted table
	D - Upper bound for wanted table
	E - Lower bound for argument table
	F - Upper bound for argument table
	G - Argument
N11	Value of N1 saved for initialization
M	Total number of outflow entries
I	Index of do loop

Symbol	Description
J1	Lower index value of a do loop used for filling out lateral inflow hydrograph entries
J	Index code for incrementing I
JC	Index code for decrementing I
KK1 (1 or 2)	Index code for a computed go to
ALPHA	First term of the right-hand side of equation 6
BETA	Second term of the right-hand side of equation 6
X1	Sum of ALPHA and BETA
SOLVE	See Solve subroutine
N3	Number of flow entries occurring after inflow ceases

Read Subroutines:

A(I1)	List items of entries being read
(I1 = 1, K1)	
I1	Index of implied do loop
K1	Number of items in list

Table Look-Up Subroutine:

X4	Look-up argument
A(J)	Look-up table
(J = 1, N2)	
J	Upper index of table bracket
K	Lower index of table bracket

Solve Subroutine:

A2(I)	Current area value for iteration
Q2(I)	Current flow value for iteration
X2	Left-hand side of equation 6
X2	Difference between X2 and X1
AU	Upper bound of area in iteration process
FAU	X2 if value of area too large
AL	Lower bound of area in iteration process
FAL	X2 if value of area too small
DELA	Area increment or decrement used to establish an upper or lower bound
ANEW	New value of area in iteration process
X3	Difference between new area value and previous area value
TOLR	Iteration cutoff

APPENDIX 1

MAIN LINE PROGRAM

```

C      STORAGE FLOOD ROUTING WITHOUT COEFFICIENTS                                001
C      *****                                                                    002
C      DIMENSION AREA1(50),DISCH1(50),Q1(100),A1(100),AREA2(50)                  003
C      DIMENSION DISCH2(50),Q2(100),A2(100),QL1(100),QL2(100)                  004
C      COMMON AREA1,DISCH1,Q1,N1,I,J,K,M,AREA2,DISCH2,A2,Q2,X1,DEL1,DEL11      005
C      COMMON N2,X4,X2,DELA,DELA1,ANEW,TOLR,X3                                  006
C      COMMON A1,DELX,QL1,QL2                                                    007
C      *****                                                                    008
C      XINT(C,D,E,F,G)=C+(((G-E)/(F-E))*(D-C))                                  009
C      C=LOWER BOUND FOR WANTED TABLE                                          010
C      D=UPPER BOUND FOR WANTED TABLE                                          011
C      E=LOWER BOUND FOR ARGUMENT TABLE                                       012
C      F=UPPER BOUND FOR ARGUMENT TABLE                                       013
C      G=ARGUMENT                                                                014
C      *****                                                                    015
C      READ PAR CARD                                                            016
C      READ1,DELT,DELT1,DELA,DELA1,TOLR,N1,N2                                  017
C      1 FORMAT(2F5.0,3F4.1,2I3)                                                018
C      *****                                                                    019
C      READ FIRST SECTION RATING AND INFLOW                                    020
C      CALL READ (AREA1,N2)                                                      021
C      CALL READ (DISCH1,N2)                                                     022
C      CALL READ (Q1,N1)                                                         023
C      CALL READ(QL1,N1)                                                         024
C      *****                                                                    025
C      CALCULATE FIRST SECTION AREAS                                           026
C      DO 10 I=1,N1                                                             027
C      CALL TBLLP(DISCH1,Q1)                                                     028
C      10 A1(I)=XINT(AREA1(K),AREA1(J),DISCH1(K),DISCH1(J),Q1(I))              029
C      *****                                                                    030
C      READ SECOND SECTION RATING AND LATERAL INFLOW                          031
C      LL1=0                                                                     032
C      LL2=0                                                                     033
C      N11=N1                                                                    034
C      59 M=N1                                                                    035
C      99 I=1                                                                    036
C      N1=N11                                                                    037
C      J1=N1+1                                                                    038
C      IF(M-N1) 952,952,951                                                      039
C      951 DO 950 J=J1,M                                                         040
C      950 QL2(J)=0.0                                                            041
C      952 CONTINUE                                                              042
C      CALL READ (AREA2,N2)                                                      043
C      CALL READ(DISCH2,N2)                                                      044
C      CALL READ(QL2,N1)                                                         045
C      *****                                                                    046
C      READ SECOND SECTION INITIAL VALUE AND DELX                             047
C      READ 2,DELX,Q2(I)                                                         048
C      2 FORMAT (F5.0,F8.0)                                                      049
C      CALL TBLLP(DISCH2,Q2)                                                     050
C      A2(I)=XINT(AREA2(K),AREA2(J),DISCH2(K),DISCH2(J),Q2(I))              051
C      J=1                                                                        052
C      N1=M                                                                        053
C      *****                                                                    054
C      ROUTING DURING INFLOW                                                    055
C      100 ALPHA=(A1(I)+A2(I))/2.                                                056
C      I=J+1                                                                      057
C      BETA=(DELT/DELX)*Q1(I)+(-A1(I)+(DELT)*(QL1(I)+QL2(I)))/2.              058

```

APPENDIX 1--Continued

MAIN LINE PROGRAM--Continued

	X1=ALPHA+BETA	059
	IF (X1)101,101,102	060
101	Q2(I)=Q2(1)	061
	A2(I)=A2(1)	062
	DELT=DELT+DELT1	063
	I=I-J	064
	J=J+1	065
	IF (J-N1)100,105,105	066
105	I=J	067
	GO TO 111	068
102	CALL SOLVE	069
	IF (Q2(I)-Q2(1)-.1)698,698,699	070
698	Q2(I)=Q2(1)	071
	A2(I)=A2(1)	072
699	CONTINUE	073
	IF (SENSE SWITCH 2) 700,701	074
700	PUNCH 702,A2(I),Q2(I),I	075
702	FORMAT (2F13.3,I3)	076
701	CONTINUE	077
	DELT=DELT1	078
	IF (I-N1)110,111,111	079
110	J=I	080
	GO TO 100	081
C	*****	082
C	ROUTING AFTER INFLOW	083
111	N3=0	084
112	J=I	085
	N3=N3+1	086
501	ALPHA=(A1(N1)+A2(I))/2.	087
	I=J+1	088
	BETA=(DELT/DELX)*Q1(N1)+(-A1(N1)+DELT*(QL1(N1)+QL2(N1)))/2.	089
	X1=ALPHA+BETA	090
	IF (X1)502,502,505	091
502	Q2(I)=Q2(1)	092
	A2(I)=A2(1)	093
	GO TO 600	094
505	CALL SOLVE	095
	IF (Q2(I)-Q2(1)-.1)502,502,601	096
601	GO TO 112	097
600	M=M+N3	098
	IF (M-100)602,602,801	099
801	M=100	100
602	CONTINUE	101
	I2=N1+1	102
	DO 900 I=I2,M	103
	QL1(I)=0.0	104
	QL2(I)=0.0	105
	A1(I)=A1(N1)	106
900	Q1(I)=Q1(N1)	107
	LL1=LL1+1	108
	LL2=LL1+1	109
C	*****	110
C	PUNCH OUT AND INTERCHANGE	111
	PUNCH 4	112
4	FORMAT(////)	113
	PUNCH 5,LL1,LL2	114
5	FORMAT(16H IN SECTION NO =I3,14X,17H OUT SECTION NO =I3)	115
	PUNCH 6	116

APPENDIX 1--Continued

MAIN LINE PROGRAM--Continued

6	FORMAT(4X,8H IN AREA,6X,9H IN DISCH,10X,9H OUT AREA,5X,10H OUT DIS	117
	1CH)	118
3	FORMAT (2F13.3,5X,2F13.3)	119
	DO 115 I=1,M	120
	PUNCH 3,A1(I),Q1(I),A2(I),Q2(I)	121
	QL1(I)=QL2(I)	122
	A1(I)=A2(I)	123
115	Q1(I)=Q2(I)	124
C	*****	125
C	INTERCHANGE RATING TABLES	126
	DO 116 I=1,N2	127
	AREA1(I)=AREA2(I)	128
116	DISCH1(I)=DISCH2(I)	129
	GO TO 99	130
800	END	131

Read and Table Look-up Subroutine

C	READ SUBROUTINE	001
	SUBROUTINE READ(A,K1)	002
	DIMENSION A(100)	003
	DIMENSION AREA1(50),DISCH1(50),Q1(100),A1(100),AREA2(50)	004
	DIMENSION DISCH2(50),Q2(100),A2(100),QL1(100),QL2(100)	005
	COMMON AREA1,DISCH1,Q1,N1,I,J,K,M,AREA2,DISCH2,A2,Q2,X1,DELI,DELI1	006
	COMMON N2,X4,X2,DELA,DELA1,ANEW,TOLR,X3	007
	COMMON A1,DELX,QL1,QL2	008
	READ 2,(A(I1),I1=1,K1)	009
2	FORMAT (9F8.0)	010
	RETURN	011
	END	012
C	TABLE LOOK-UP SUBROUTINE	001
C	A=ARGUMENT TABLE	002
C	B=ARGUMENT	003
	SUBROUTINE TBLLP(A,B)	004
	DIMENSION A(100),B(50)	005
	DIMENSION AREA1(50),DISCH1(50),Q1(100),A1(100),AREA2(50)	006
	DIMENSION DISCH2(50),Q2(100),A2(100),QL1(100),QL2(100)	007
	COMMON AREA1,DISCH1,Q1,N1,I,J,K,M,AREA2,DISCH2,A2,Q2,X1,DELT,DELT1	008
	COMMON N2,X4,X2,DELA,DELA1,ANEW,TOLR,X3	009
	COMMON A1,DELX,QL1,QL2	010
	X4=B(I)	011
	IF (X4)16,15,16	012
15	J=2	013
	GO TO 20	014
16	DO 30 J=1,N2	015
	IF (A(J)-X4)30,20,20	016
20	K=J-1	017
	RETURN	018
30	CONTINUE	019
	END	020

APPENDIX 1--Continued

Solve Subroutine

C	SOLVE ROUTINE	001
	SUBROUTINE SOLVE	002
	DIMENSION AREA1(50),DISCH1(50),Q1(100),A1(100),AREA2(50)	003
	DIMENSION DISCH2(50),Q2(100),A2(100),QL1(100),QL2(100)	004
	COMMON AREA1,DISCH1,Q1,N1,I,J,K,M,AREA2,DISCH2,A2,Q2,X1,DELT,DELT1	005
	COMMON N2,X4,X2,DELA,DELA1,ANEW,TOLR,X3	006
	COMMON A1,DELX,QL1,QL2	007
	XINT(C,D,E,F,G)=C+((G-E)/(F-E))*(D-C)	008
	AU = 0.	009
	FAU = 0.	010
	AL = 0.	011
	FAL = 0.	012
	DELA = DELA1	013
	IF (I-N1) 800,800,801	014
801	A2(I)=A1(N1)	015
	GO TO 11	016
800	A2(I)=A1(I)	017
11	CALL TBLLP(AREA2,A2)	018
	Q2(I)=XINT(DISCH2(K),DISCH2(J),AREA2(K),AREA2(J),A2(I))	019
	IF (SENSE SWITCH 1) 700,701	020
700	PUNCH 702,A2(I),Q2(I),I	021
702	FORMAT (2F13.3,I3)	022
701	CONTINUE	023
	X2=(DELT/DELX)*Q2(I)+(A2(I))/2.	024
	X2=X2-X1	025
	IF (X2) 3,5,2	026
2	DELA=DELA1	027
	AU=A2(I)	028
	FAU=X2	029
	IF (AL) 4,12,4	030
12	A2(I)=A2(I)-DELA	031
13	IF (A2(I)) 7,7,11	032
7	DELA=DELA*.5	033
	A2(I)=A2(I)+DELA	034
	GO TO 13	035
3	DELA=DELA1	036
	AL=A2(I)	037
	FAL=-X2	038
	IF (AU) 4,14,4	039
14	A2(I)=A2(I)+DELA	040
15	IF (A2(I)-AREA2(N2)) 11,11,16	041
16	DELA=DELA*.5	042
	A2(I)=A2(I)-DELA	043
	GO TO 15	044
4	ANEW=AU-(FAU/(FAU+FAL))*(AU-AL)	045
	X3=ANEW-A2(I)	046
	X3=ABS(X3)	047
	IF (X3-TOLR) 5,5,10	048
10	A2(I)=ANEW	049
	GO TO 11	050
5	A2(I)=ANEW	051
	CALL TBLLP(AREA2,A2)	052
	Q2(I)=XINT(DISCH2(K),DISCH2(J),AREA2(K),AREA2(J),A2(I))	053
	RETURN	054
	END	055

APPENDIX 2

Program Input Format¹

Parameter Card 1:

1-5	6-10	11-14	15-18	19-22	23-25	26-28
XXXXX	XXXXX	XXX.X	XXX.X	XXX.X	XXX	XXX
DELT	DELT	DELA	DELA1	TOLR	N1	N2

Hydrograph and Rating Table Entries:

1-8	9-16	17-24	25-32	33-40	41-48
XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.
49-56	57-64	65-72	73-80 ²		
XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.	XXXXXXXXX.		

Parameter Card 2:

1-5	6-13
XXXXX.	XXXXXXXXX.

Program Output Format¹

Inflow and Outflow Values:

1-13	14-26	32-44	45-57
XXXXXXXXXXXXXXX.XXX	XXXXXXXXXXXXXXX.XXX	XXXXXXXXXXXXXXX.XXX	XXXXXXXXXXXXXXX.XXX
A1 (I)	Q1 (I)	A2 (I)	Q2 (I)

Loading Sequence

1. Parameter card 1
2. Flow area portion of inflow section rating table
3. Flow portion of inflow section rating table
4. Inflow hydrographs at inflow section
5. Lateral inflow at inflow section
6. Flow area portion of outflow section rating table
7. Flow portion of outflow section rating table
8. Lateral inflow at outflow section
9. Parameter card 2

¹Decimal is shown at its implied position. If another position is required, it should be punched.

²Columns 73-80 are reserved for identification, such as card number, card type, section number, watershed location, etc.

U. S. DEPARTMENT OF AGRICULTURE
Agricultural Research Service
Beltsville, Maryland 20705

Official Business

Postage and Fees Paid
U. S. Department of Agriculture